

ProSeries® Resettable Combination Padlock Instructions.

*Refer to the tiny, Master Lock document for illustrations,
Refer to this larger, R&M copy for print big enough to read comfortably*

To set your own combination:

(REMEMBER: Combination can only be set when lock is open)

- 1. TURN shackle 90° to the BACK of the lock.**
- 2. DEPRESS shackle into lock until seated.**
- 3. TURN shackle again 90° to the SIDE of the lock.**
- 4. SET dials at black indicator line to desired combination.
BE SURE TO RECORD YOUR COMBINATION.**
- 5. PULL shackle UP. VERIFY dials remained set to your combination.
Lock is now set to new combination.
Note: If dials shifted, the combination was not set; return to step one.
Note: The dials of a lock with a valid combination do not rotate when the shackle is open.**

**To Lock: TURN shackle 180° and DEPRESS the shackle into the lock.
SCRAMBLE the dials.**

To Reopen: DIAL your combination and PULL shackle.

[rm-info-padlocks-master-reset-enlarged.pdf]